



# Automated MicroPlastic Detector

Justin Bahr, Carson Dang, Phi Hoang, Hari Narayananam,  
Alexander Pervizi, Ananya Tadigadapa, Jonathan Qi

Advisor: Professor Canek Fuentes – C1

# **What are Microplastics?**


- Plastic pieces between 1 um – 5mm
- Insoluble in water
- Typically invisible to the eye
- Health impacts are being actively researched



*According to a 2019 study:*

The Average American  
ingests more than  
**70,000 MPs per year**  
in their drinking  
water supply...

...or a **credit card** every week.



“Public health is at risk from microplastic content in our drinking water!”

# Existing Solutions

Tap Score  
Sample Testing  
\$579



**EXPENSIVE  
COMPLEX  
INEFFICIENT**

Raman/FT-Infrared  
Spectroscopy  
\$10,000+



# **Value Proposition**

**Our solution (AMP'D) will provide a system to test for microplastics at home.**





**Affordable**

**Intuitive**




**Rapid**

# **Project Development Journey**

# Preliminary Research





# Refraction



- Utilizes optical principles; refraction indices
- Equipment is expensive and sensitive

# Impedance Plates



- Detects microplastics through impedance spikes
- Experienced low signal-to-noise ratio

# **How can we utilize this research in a capstone project?**


Goals: Affordable, Intuitive, Rapid

# Final Decision: Dual-Method Solution

## Part 1: Impedance with TDS Modules

### *Modification of flow cells*

- Uses multiple Total Dissolved Solids module to check for changes in conductivity caused by plastics



## Part 2: Scattering with CMOS Camera

### *Modification of refraction*

- Uses a camera to detect refracted beams from the presence of plastics in the water






# **AMP'D**


# **Product Design**

# Impedance Probes




Two Total Dissolved Solids (TDS) Modules


Measuring Conductance



Modified Capacitor for Alternative Frequency



- TDS Module Circuitry :



# Electrical Post Processing

- ADC Breakout Board



DC  
Voltage



Rectifier &  
Low Pass  
Smoothing

SPI

Raspberry Pi 3




# Optics





- CMOS Camera perpendicular to direction of the laser
- As water flows, microplastics scatter the collimated beam into the camera


# Mechanical Housing



# Electrical Housing

Relay  
Raspberry Pi  
TDS Modules





# Software

Changeable Variables

Status/Monitoring

Testing Controls

Progress Logs




Data Analysis

Graph of collected raw data

Upload Data Online

# Software




# Impedance Analysis

- Measuring water's impedance at multiple frequencies allows us to calculate:
  - Capacitance
  - Conductivity
  - PPM
- Gives a detailed look into the water's contents
  - Metals and minerals increase conductance
  - Microplastics decrease capacitance





# Camera Analysis



# Software

The Firebase console interface. At the top left is the Firebase logo. Below it are two main sections: "Collections" and "Documents". Under "Collections", there are entries for "User 1", "User 2", and "...". Under "Documents", there are entries for "Sample 1" and "Sample 2", with "..." below them. A modal window titled "Upload Experiment Results" is open at the bottom, containing fields for "Title" (set to "cd\_experiment\_data"), "Upload Data", "Upload Impedance Analysis", "Upload Camera Analysis", and "AMP'D Account Information" (with email "capstone@neu.edu" and password "123456"). There is also an "Upload" button and a "Device Status" indicator showing "Ready to upload".



# Software

EXPERIMENTS 

AMP'D

LOGOUT

  
**EXPORT DATA**

Compare View

04/08/2025 06:40

04/08/2025 06:28

04/08/2025 06:28 Water Sample Report


Microplastic Content

"Impedance Analysis Results"  
**Plastic Present**  
Estimated ppm: 83.95148568057145


"Camera Analysis Results"  
**Plastic Present**  
Average Scattered Light: 1417.5


SEE MORE

Impedance Results



Frame from Camera Analysis





# Product Cost

**Product Cost**  
\$200


**Total Spent**  
\$575.47

**Amount Under Budget**  
\$124.53

# Total Budget

## Spending Categories

- Optics
- Housing
- Electronics
- Impedance Spectroscopy




# Conclusion

# Results and Impact

## Rapid, Accurate Microplastic Detection

- Sensitive to concentrations of PVC particles as low as 400  $\mu\text{m}$
- Testing and analysis complete within minutes
- Intuitive & descriptive delivery of analysis results available through a webpage



# Extension of Work


## Filtration & Characterization

- Purification of contaminated water after tested
- Characterization of shape, size & weight



## Improved Impedance Spectroscopy

- Introduce Parallel plate electrodes & superimposed sinusoidal input signals with different frequencies



## Alternate Methods of Detection

- Fluorescence based detection?

	Stereomicroscope				Fluorescence microscope
	Unstained	Ethanol	Distilled water	Acetone	
PE					
PP					
PVC					
PS					
PU					

# A picture is worth a thousand words



# Thank you!


- Any Questions?



## TDS Module Signal:

The TDS Module outputs a 400 mV peak-to-peak (200 mV RMS  $V_{in}$ ) square wave to the probe.

The signal frequency is controlled by an IC connected to an RC timing circuit as shown below:




The oscillation frequency for the first (unmodified) module is given by the equation below:

$$f_H = \frac{1}{0.602 \cdot 2\pi(R_1 + R_5)C_4} = \frac{1}{0.602 \cdot 2\pi(100K + 10K)1n} = \frac{1}{0.00013244\pi} = 2.403 \text{ kHz}$$

The second module has a 2.14 nF capacitor soldered in parallel with C5, and its oscillation is given by the equation below:

$$f_L = \frac{1}{0.602 \cdot 2\pi(R_1 + R_5)(C_4 + 2.14n)} = \frac{1}{0.602 \cdot 2\pi(100K + 10K)(1n + 2.14n)} = \frac{1}{0.0013064677\pi} = 765 \text{ Hz}$$

## Transimpedance Amplifier:



Transimpedance gain A is given by:

$$V_{out} = AI_{in} = -I_{in}R_f$$

$$A = -R_f = -R_{10} = -5600 \text{ V/A}$$

$$\text{ppm} = 133.42V_{ADC}^3 - 255.86V_{ADC} + 857.39V_{ADC}$$

Can be linearized for normal tap water:

$$\text{ppm} \approx 146.6V_{ADC}$$

## Calculating Water Impedance based on $V_{out}$ :


$V_{out}$  is then passed through a rectifier and low pass filter to obtain an DC analog output signal  $V_{ADC}$ , which is read by the ADC.

$V_{ADC}$  is approximately given by the RMS value of  $V_{out}$ :  $V_{ADC} \approx \text{RMS}\{V_{out}\} = |A|I_{in}$

$$V_{in} = I_{in}|Z_{water}| = \frac{V_{ADC}}{|A|}|Z_{water}|$$

$|Z_{water}| = \frac{|A|V_{in}}{V_{ADC}} = \frac{5600 \cdot 200}{V_{ADC}}$ , where  $V_{ADC}$  is read in mV and  $|Z_{water}|$  is given in  $\Omega$ .

### Approximate Water Impedance Model:



$$Z_{water} \approx R_{water} \parallel j\omega C_{water} = \frac{R_{water}}{1 + 2\pi f R_{water} C_{water}}$$

## Calculating Water RC Constant based on Impedance at Multiple Frequencies:

The water's impedance is given by  $Z_H$  for the high frequency and  $Z_L$  for the low frequency.

$$|Z_H|^2 = \frac{R_{\text{water}}^2}{1 + 4\pi^2 f_H^2 R_{\text{water}}^2 C_{\text{water}}^2} \quad \text{and} \quad |Z_L|^2 = \frac{R_{\text{water}}^2}{1 + 4\pi^2 f_L^2 R_{\text{water}}^2 C_{\text{water}}^2}$$

$$|Z_H|^2(1 + 4\pi^2 f_H^2 R_{\text{water}}^2 C_{\text{water}}^2) = |Z_L|^2(1 + 4\pi^2 f_L^2 R_{\text{water}}^2 C_{\text{water}}^2)$$

$$|Z_H|^2 + 4|Z_H|^2 \pi^2 f_H^2 R_{\text{water}}^2 C_{\text{water}}^2 = |Z_L|^2 + 4|Z_L|^2 \pi^2 f_L^2 R_{\text{water}}^2 C_{\text{water}}^2$$

$$4|Z_H|^2 \pi^2 f_H^2 R_{\text{water}}^2 C_{\text{water}}^2 - 4|Z_L|^2 \pi^2 f_L^2 R_{\text{water}}^2 C_{\text{water}}^2 = |Z_L|^2 - |Z_H|^2$$

$$4\pi^2 R_{\text{water}}^2 C_{\text{water}}^2 (|Z_H|^2 f_H^2 - |Z_L|^2 f_L^2) = |Z_L|^2 - |Z_H|^2$$

$$R_{\text{water}}^2 C_{\text{water}}^2 = \frac{|Z_L|^2 - |Z_H|^2}{4\pi^2 (|Z_H|^2 f_H^2 - |Z_L|^2 f_L^2)} = K$$

$$R_{\text{water}} C_{\text{water}} = \frac{\sqrt{|Z_L|^2 - |Z_H|^2}}{2\pi \sqrt{|Z_H|^2 f_H^2 - |Z_L|^2 f_L^2}}$$

$$|Z_H|^2 = \frac{R_{\text{water}}^2}{1 + \frac{1}{4\pi^2 f_H^2 C_{\text{water}}^2}}$$

$$R_{\text{water}}^2 = |Z_H|^2 \left(1 + 4\pi^2 f_H^2 K\right)$$

$$R_{\text{water}} = |Z_H| \sqrt{1 + 4\pi^2 f_H^2 K}$$

$$R_{\text{water}}^2 C_{\text{water}}^2 = K$$

$$C_{\text{water}}^2 = \frac{K}{R_{\text{water}}^2}$$

$$R_{\text{water}} = \sqrt{|Z_H|^2 - \frac{1}{4\pi^2 f_H^2 C_{\text{water}}^2}}$$

$$C_{\text{water}} = \frac{\sqrt{K}}{R_{\text{water}}}$$